



## Provides the ability to wirelessly control various home appliances

### Andromeda Socket

#### INDEPENDENCE

Andromeda Socket is specially adapted for people with functional disabilities who want to live a more independent life and can turn on and off lamps, turn on and off various appliances wirelessly. It can easily be moved between different wall sockets.

#### FLEXIBLE CONTROL METHOD

It can be controlled in three different ways, with an IR transmitter, a Z-Wave transmitter or a connected control switch.

Art.nr: : 419881



**ABILIA**

## PRACTICE CAUSE AND EFFECT

With a connected control switch, it is possible to practice cause and effect, for example connecting an electric mixer that runs as long as the control switch is pressed.

## BUILT IN ON/OFF BUTTON

Andromeda Socket also has a built-in on/off button that makes it possible to operate the device even if one has no IR/Z-Wave transmitter. It also has a blue indication light that shows if there is power at the socket.

## EASY TO PROGRAM

It is easy to program, as is done with the builtin on/off button.

Andromeda socket is available in different versions for different countries



### TECHNICAL DATA

Operating voltage: 230V AC, 50 Hz  
Maximum relay load: 2990 VA 13A, resistive load  
Programming channels IR: GewaLink channels  
Radio system: Z-Wave  
Radio frequency: 868.42 MHz  
Input control switch type: 3.5 mm (2-pole mono female)  
Operating environment: Indoors  
Measurements: 53 x 122 x 43mm (excl. plug)